



Spare parts for IPU10
safety lifting clamps:

	Order no.
1. body complete	1041
2. hoisting eye complete	1235
3. camsegment complete	1234
4. latch complete	1233
5. spring for latch complete	1063
6. camsegment shaft complete	1046
7. hoisting eye shaft complete	1047
10. pivot complete (round)	0098

3, 5 and 10 are included
in maintenance set till 6 tonnes

3, 4, 5, 6, 7 and 10 are included
in revision set till 6 tonnes